





- . Tecnodeck profiles must always work together with metal reinforcement profiles.
- . The fixation of Tecnodeck profiles must be made to the metal reinforcement profiles and never to the composite profiles.
- . Please validate the fixations with Tecnodeck technical department.
- . For quantities, bespoke profiles are possible under request.
- . Distances between supports:














When fixing with screws profiles:



- Inner structural profile;
- Needs a 1mm/m gape betwen top profiles;




- Use a inner bushing to prevent smashing wpc profile;
- Protect the wpc with oversize washers



- Consider wpc hole diameter at least 4mm more than bushing outside diameter;
- Structural profile hole diameter equal to bushing outside diameter.
- All these parameters must be considered in any WPC profile, such as 85x85, 85x30 and 30x22.

• Some different examples:



• If in any doubt, please contact TECNODECK.



Tel : +33 442 189 142 Fax : +33 442 189 285 Email : info@kplastexport.fr